MAGNETIC WALLPAPER



THE RIGHT UNDERGROUND/ PREPARATION -

Which undeground?

Groovy Magnets wallpaper adheres to almost any smooth indoor surface such as: smooth painted walls and doors, metal, wood, glass, cardboard, paper, plastic, kitchen cabinets,..

Smooth & clean

If necessary, **smooth and sand down any bumps** (uneveness in the wall can remain visible through the wallpaper).

Any surface should be **degreased**, **dust-free and dry:** Clean well with lukewarm water and cleaning vinegar. Rinse and allow to dry thoroughly before you start wallpapering.

Painted walls / doors

Painted walls and doors are suitable undergrounds for installing magnetic wallpaper. **Allow a freshly painted**

APPLICATION —

Always start walpapering on a flat, degreased, dust-free & dry surface.

Determine position

Think outside the box: a wallpaper panel can be hung **both horizontally and vertically.** Draw a perpendicular line on the surface where the wallpaper will be applied. A plumb bob or a spirit level can be helpful here.

TIP multiple strokes: before applying multiple wallpaper strokes of black wallpaper: paint a black line on the wall where 2 strokes will meet -> no gap will be visible in case the strokes don't fit perfectly!

The right glue & amount

Because magnetic wallpaper is heavier than regular wallpaper, it is very important to use the right adhesive. **Use ready-to-use wall glue for vinyl wallpaper**. One 750g pot will be sufficient for one strip of magnetic wallpaper measuring 102x265cm.

! Do not use self-dissolving wallpaper paste based on powder.

underground to dry for at least two weeks before applying the wallpaper to get the moisture out of the surface.

Painted surfaces based on acrylic or coated paint should be lightly sanded and cleaned. Finish-sand before start pasting the surface for better grip.

Stucco & untreated wood

For strongly absorbent surfaces such as plaster or untreated wood, **pre-gluing** is recommended (for method, see: *pre-gluing*). **Freshly plastered walls must be 100% dry.**

Wooden panel

For a stylish non-permanent alternative you can also wallpaper a wooden panel. Attach the panel to the wall with corner screws. Remember to glue the back of an untreated panel (such as MDF) as well to prevent it from warping. Water-resistant MDF (green), has no risk of warping so gluing the backside is not necessary here.

Pre-gluing?

If you aren't sure whether your surface is absorbent or not, **test by spraying water to the surface with a plant sprayer**. In case colour change appears within 3 mins: pregluing is necessary.

Pre-gluing method:

Dilute the glue with a little water and spread 1 layer of the mixture on the surface with a glue roller. When the surface feels dry (after about 15 min), start gluing in for wallpapering.

Gluing the underground

- First check whether pre-gluing is required (see chapter: Pre-gluing).
- Mark the width of the strip on the wall so that you know up to where you have to apply the glue.
- Spread the glue directly onto the surface with a glue roller. Glue one strip at a time. Use enough glue where the edges of the wallpaper will be. Did you spill? No panic. You can remove spilled glue with a damp cloth and some washing-up liquid (do it immediately).

Applying the wallpaper

Ask for a helping hand to hold the wallpaper roll in place or fix the wallpaper at the top with a piece of strong tape to keep it in place. It is recommended to start wallpapering from the top and roll off.

Remove bubbles

Press the wallpaper firmly with a soft pressure roller / soft cloth towards the edges to remove any air bubbles.

Trim

Cut to size at top or bottom using a ruler and a sharp cutter knife.

Before you start using the wallpaper

After application, allow the wallpaper to dry for at least 24 hrs before sticking magnets up on the wall.

Removing the wallpaper

Due to the waterproof structure of magnetic wallpaper, it is not possible to soak it off. However, it is possible to remove the wallpaper from the wall: **Start pulling down from a corner and slowly pull downwards.** Any remaining textile backing can be removed by moistening it with a plant sprayer filled with lukewarm water. Remove with a putty knife.

CARE & USAGE -

Cleaning the wallpaper

All our wallpapers are water-resistant. **Clean with a damp cloth and a drop of washing-up liquid.** Remove stubborn streaks with a **wonder sponge** (melamine sponge) + a drop cleaning vinegar and washing-up liquid.

Writable wallpaper

Consult the product pages on our website for the right use of writing material suitable for your type of wallpaper.

Paintable wallpaper

This wallpaper is paintable with all types of wallpaint. The magnetic effect remains even after 2 layers of paint.

