MAGNETIC STICKERS

This manual is available on our website in Dutch, French, German and English www.groovymagnets.com

THE RIGHT UNDERGROUND

Go through this manual before applying the sticker to make sure you have the right tools at hand.

Flat / smooth

Groovy Magnets magnetic stickers adhere to almost any smooth surface such as: metal, wood, glass, cardboard, paper, plastic, kitchen cupboards, smooth painted walls and doors.

If necessary, smooth and sand down any bumps. Small bumps or unevenness in the surface can remain visible through the sticker afterwards.

Clean

Degrease the surface with lukewarm water and cleaning vinegar. Rinse again with lukewarm water. Do not use ammonia when cleaning because it can affect the adhesive of the sticker.

Slightly sand painted walls and doors on acrylic basis or coatings. Let a freshly painted wall dry for at least two weeks before applying the wall stickers.

Use indoors

Groovy Magnets magnetic stickers are suitable for use indoors.

APPLYING THE STICKER

Avoid air tunnels

Stick the sticker on the wall within 2 hours after removing it from the packaging. When a rolled-up sticker is opened, air tunnels may occur in the backing sheet which can dry out the adhesive layer.

Determine position

Tip: Before you finally apply the sticker, you can temporarily hang it in the desired position without removing the backing sheet. Do this with a piece of strong tape and mark the edges as a reference point.

Stick it on

First remove part of the top of the backing sheet from the sticker. Position the sticker on the base and press firmly. Now gently pull the back sheet further downwards and work your way to the bottom. Meanwhile, rub the sticker firmly with a soft cloth or a (soft) pressure roller.

! Important

To ensure that the glue sticks properly to the wall, a hair dryer comes into play. Heat the front and the edges of the sticker with a hair dryer and press firmly. The heat makes the glue supple and gives optimum adhesion.

Removing the sticker

Warm the sticker with a hairdryer and carefully peel it off bit by bit. Always keep heating every piece well. Depending on the surface, the adhesive strength of the sticker may be good enough to reuse the sticker. If not, you can reattach it with some extra wallpaper glue*.

Depending on the substrate or the quality of the painted surface, it will be easier to remove the sticker. The longer the sticker is on a substrate, the more firmly it sticks. For a smooth painted surface removing will be easier than for a wallpapered wall.

* All information about the right glue can be found on our website.

MAINTENANCE & USE

You can clean all our magnetic stickers with a damp cloth and a drop of washingup liquid.

CHALKBOARD MAGNETIC STICKER

- Writable with soft chalk. Avoid liquid chalk markers, as they leave permanent marks.
- Clean with a damp cloth. Remove stubborn marks with a wonder (melamine)-sponge with a dash of cleaning vinegar and a drop of washingup liquid.

WRITABLE MAGNETIC STICKER

- Writable with chalk markers. Do not use chalk because it scratches.
- Clean with a damp cloth. Remove stubborn marks with a wonder (melamine)-sponge with a dash of cleaning vinegar and a drop of washingup liquid.

ENJOY Your New Functional Wall!

Groovy Magnets